




20399 20396 26200
BOCCA A PAVIMENTO BOCCA DA PARETE
/ FREESTANDING SPOUT / WALL-MOUNTED SPOUT

30601 30601
COMANDO REMOTO COMANDO REMOTO
ELETTRONICO PER ELETTRONICO PER
BOCCA DA BANCO BOCCA DA BANCO
/ ELECTRONIC / ELECTRONIC
SEPARATE CONTROL SEPARATE CONTROL
FOR COUNTER SPOUT FOR COUNTER SPOUT

30501 20813
RUBINETTO PORTA DISPENSER A
ELETTRONICO LAVABO MURO / WALL-MOUNTED
/ ELECTRONIC BASIN SOAP DISPENSER
MIXER HOLDER

20099 20114
BOCCA DA SOFFITTO BOCCA DA PARETE
/ CEILING-MOUNTED / WALL-MOUNTED
SPOUT SPOUT



30542
RUBINETTO
ELETTRONICO LAVABO
CON LED / ELECTRONIC
BASIN MIXER WITH LED



30531 23099
RUBINETTO BOCCA DA SOFFITTO
ELETTRONICO LAVABO / CEILING-MOUNTED
/ ELECTRONIC BASIN SPOUT
MIXER


30521 13300
RUBINETTO BOCCA DA PARETE
ELETTRONICO LAVABO / WALL-MOUNTED
/ ELECTRONIC BASIN SPOUT
MIXER

23093 30622
BOCCA DA BANCO COMANDO REMOTO
/ COUNTER SPOUT ELETTRONICO PER
BOCCA DA PARETE
/ ELECTRONIC
SEPARATE CONTROL
FOR WALL-MOUNTED
SPOUT





30511




30601
30603



26191



26193




30602
30604



30629_30619



20099
L. 1600 mm
20199
min 50 - max 1800 mm




26200



ElectroniciProductlist

277


Finishings: 031 Cromo - Chrome
149 Finox - Finox



30501



30541
Colour **30542**




30601
30603



H. 158 L. 144 mm **20094**
H. 158 L. 203 mm **20098**



H. 308 L. 203 mm **20091**



L. 197 mm **20114**
Min 70 max 300 mm **20118**



30602
30604



30629_30619




20399_20396




20099
L. 1600 mm **20199**
min 50 - max 1800 mm




ElectroniciProductlist




30531




30521



20091




23093




**30621
30622**



**30622
30624**



L. 166 mm **13300**
L. 231 mm **13303**




23095



23099
L. 1600 mm

23199
min 50 - max 1800 mm



23103



ElectroniciProductlist

281

Finishings: **031** Cromo - Chrome
149 Finox - Finox